



## DxO Optics Pro 6 Elite Edition Supported equipment



CANON
Canon EOS 1D Mark II
Canon EOS 1D Mark II N
Canon EOS 1D Mark III
Canon EOS 1D Mark IV
Canon EOS 1Ds
Canon EOS 1Ds Mark II
Canon EOS 1Ds Mark III
Canon EOS 5D
Canon EOS 5D Mark II
Canon EOS 7D
Canon EOS 10D
Canon EOS 20D
Canon EOS 30D
Canon EOS 40D
Canon EOS 50D
Canon EOS 60D
Canon EOS D60
Canon EOS 300D or Digital Rebel or Kiss Digital
Canon EOS 350D or Digital Rebel XT or Kiss Digital N
Canon EOS 400D or Digital Rebel XTi or Kiss Digital X
Canon EOS 450D or Digital Rebel XSi or Kiss X2
Canon EOS 500D or Digital Rebel T1i or Kiss Digital X3
Canon EOS 550D or Digital Rebel T2i or Kiss X4
Canon EOS 600D or Digital Rebel T3i or Kiss X5
Canon EOS 1000D or Digital Rebel XS or Kiss F
Canon EOS 1100D or Digital Rebel T3 or Kiss X50
Canon PowerShot G9
Canon PowerShot G10
Canon PowerShot G11
Canon PowerShot G12
Canon PowerShot S2-IS
Canon PowerShot S90
Canon PowerShot S95

FUJI
Fuji S100FS
Fuji S3
Fuji S5
Fuji FinePix S9500 or FinePix S9000

KODAK
Kodak P850
Kodak P880

KONICA MINOLTA
Konica Minolta DiMAGE A2
Konica Minolta DiMAGE A200
Konica Minolta DiMAGE Z6
Konica Minolta DYNAX 5D or MAXXUM 5D
Konica Minolta DYNAX 7D or MAXXUM 7D

NIKON
Nikon Coolpix 8800
Nikon Coolpix P7000
Nikon D2H
Nikon D2X
Nikon D2Xs
Nikon D3
Nikon D3S
Nikon D3X
Nikon D40
Nikon D40X
Nikon D50
Nikon D60
Nikon D70
Nikon D70s
Nikon D80
Nikon D90
Nikon D100
Nikon D200
Nikon D300
Nikon D300S
Nikon D700
Nikon D3000
Nikon D3100
Nikon D5000
Nikon D5100

OLYMPUS
Olympus E-3
Olympus E-5
Olympus E-30
Olympus E-410
Olympus E-420
Olympus E-450
Olympus E-510
Olympus E-520
Olympus E-620
Olympus PEN E-PL1
Olympus PEN E-PL2
Olympus SP-500UZ

PANASONIC
Panasonic Lumix FZ30
Panasonic Lumix LX3
Panasonic Lumix LX5
Panasonic GH-1
Panasonic GH-2
Panasonic GF-1
Panasonic GF-2

PENTAX
Pentax K10D
Pentax K20D
Pentax K200D
Pentax K-5
Pentax K-7
Pentax K-m
Pentax K-r
Pentax K-x

SAMSUNG
Samsung Digimax Pro815
Samsung GX20

SONY
Sony NEX-3
Sony NEX-5
Sony Alpha 100
Sony Alpha 200
Sony Alpha 230
Sony Alpha 290
Sony Alpha 300
Sony Alpha 330
Sony Alpha 350
Sony Alpha 380
Sony Alpha 390
Sony Alpha 450
Sony Alpha 500
Sony Alpha 550
Sony Alpha 580
Sony Alpha 700
Sony Alpha 850
Sony Alpha 900
Sony SLT-A33
Sony SLT-A55
Sony DSC-F828
Sony DSC-H1
Sony DSC-R1